

ASSEMBLY INSTRUCTIONS

1907

1. SCREW SOCKET ASSEMBLY INTO BASE THROUGH COLLAR RING.
2. SCREW PIPE INTO TOP OF SOCKET ASSEMBLY.
3. SCREW BULBS (NOT INCLUDED) INTO SOCKET ASSEMBLY.
4. SLIDE MIDDLE CAP ONTO PIPE.
5. PLACE SHADE ON MIDDLE CAP AND TIGHTEN DOWN (HAND TIGHT ONLY) WITH TOP CAP AND FINIAL.

**TO CLEAN, USE SOFT CLOTH ONLY.

**DO NOT USE ANY CHEMICAL OR ABRASIVE CLEANERS.

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

FOR REPLACEMENT PARTS OR FOR ADDITIONAL INFORMATION,

GOTO OUR WEBSITE www.legacylamp.com or CALL 877-353-5999 M-F 9a-4p CST

