

# ASSEMBLY INSTRUCTIONS

## 1859

1. PLACE HARP ON SADDLE.
2. PLACE WASHER ON HARP.
3. PLACE SHADE ON HARP AND TIGHTEN FINIAL.


**\* TO CLEAN, USE SOFT CLOTH ONLY.**

**\* DO NOT USE ANY CHEMICAL OR ABRASIVE CLEANERS.**

## IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

FOR REPLACEMENT PARTS OR FOR ADDITIONAL INFORMATION,  
GOTO OUR WEBSITE [www.legacylamp.com](http://www.legacylamp.com) or CALL 877-353-5999 M-F 9a-4p CST



2007.02.27 停設. 加Wob 和 Time.